

Ah-Hoc, PAN, WSN, ...

- Introduction
- Bluetooth (802.15.1)
- Zigbee (802.15.4)

Renato Lo Cigno
www.dit.unitn.it/locigno/

Ad-Hoc Networks

- Built by the users themselves to support specific (in time, space, applications) needs
 - Example: using 802.11 BSS as you did in the lab
- Are generally closed, but "gateways" are coming into play to connect them to the rest of the world
- The key point is the requirement to build and support dynamically the topology "on-the-fly"
 - No network planning
 - No hierarchy
 - No engineering



Sensor/Actuators Networks

- Ad-Hoc networks whose goal is specifically making some kind of measure (sensing) and, in case, react to some change/event (actuating)
- Normally battery powered: one more problem on energy consumption
- Are the backbone of "Ambient Intelligence" concepts



Personal Networks

- PAN "personal area network"
- IEEE 802.15 sub-project
- Very short range (1-5m) and extremely low power (< 10mw EIRP)
- The goal is connection of devices for "cable replacement"
 - Earphone with cell/HiFi/TV
 - PDA, cell phone, clock, alarm, laptop
 - mouse, keyboard, laptop
 - ...



Technologies

- 802.11
 - Do you know it? ☺
- Bluetooth (802.15.1)
 - Master/Slave architecture
 - Optimized for low bandwidth (< 1Mbit/s), real time communications
- ZigBee (802.15.4)
 - Meshed architecture
 - Low power consumption
 - Suitable for sporadic communications with very low throughput (channel capacity 25 kbit/s)
- All use the same ISM bands




Open (Not Yet Standard) Issues

- Routing
 - How to find the best route across a "temporary" network?
 - Coordination of multi-hop transfer
 - Stability of routes
- Topology Management
 - Cooperation among nodes
 - How to reward nodes that use resources for others
- Usage context
 - Ad Hoc Networks were born for military applications
 - Their civilian use is appealing, but do we really need them?



Bluetooth


Bluetooth Specifications



- A hardware/software/protocol description
- An application framework



Bluetooth Radio Specification



Design considerations

Goal

- high bandwidth
- conserve battery power
- cost < \$10

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 10

Bluetooth radio link

- frequency hopping spread spectrum
 - 2.402 GHz + k MHz, k=0, ..., 78
 - 1,600 hops per second
- GFSK modulation
 - 1 Mb/s symbol rate
- transmit power
 - 0 dbm (up to 20dbm with power control)

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 11

Baseband

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 12

Bluetooth Physical link


• Point to point link

- master - slave relationship
- radios can function as masters or slaves



• Piconet

- Master can connect to 7 slaves
- Each piconet has max capacity = 1 Mbps
- hopping pattern is determined by the master




Renato.LoCigno@dit.unitn.it

Nomadic Communications: Short Range Networks 13

Connection Setup

• Inquiry - scan protocol

- to learn about the clock offset and device address of other nodes in proximity




Renato.LoCigno@dit.unitn.it

Nomadic Communications: Short Range Networks 14

Piconet formation

• Page - scan protocol

- to establish links with nodes in proximity



Renato.LoCigno@dit.unitn.it


Nomadic Communications: Short Range Networks 15

Addressing

- Bluetooth device address (BD_ADDR)
 - 48 bit IEEE MAC address
- Active Member address (AM_ADDR)
 - 3 bits active slave address
 - all zero broadcast address
- Parked Member address (PM_ADDR)
 - 8 bit parked slave address



Piconet channel



Packet Header




Purpose


- Addressing (3) → Max 7 active slaves
- Packet type (4) → 16 packet types (some unused)
- Flow control (1) → Broadcast packets are not ACKed
- 1-bit ARQ (1) → For filtering retransmitted packets
- Sequencing (1)
- HEC (8) → Verify header integrity


total 18 bits

Encode with 1/3 FEC to get 54 bits









Baseband: Summary

The diagram shows two devices, Device 1 and Device 2, connected via a Physical link. Each device contains an LMP layer, an L2CAP layer, and a Baseband layer. Data flows from L2CAP to LMP and then to Baseband, and vice versa. The Physical link connects the Baseband layers of both devices.

- TDD, frequency hopping physical layer
- Device inquiry and paging
- Two types of links *SCO* (Sync. Connection Oriented) and *ACL* (Async. ConnectionLess) links
- Multiple packet types (multiple data rates with and without FEC)

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 22

Link Manager Protocol

The diagram shows a protocol stack with Applications (SDP, IP, RFCOMM) on top, followed by Data, L2CAP, Link Manager, Baseband, and RF at the bottom. A Control plane is shown on the right, and LMP is indicated as a protocol between Link Manager and Baseband.

Setup and management of Baseband connections

- Piconet Management
- Link Configuration
- Security

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 23

Piconet Management

- Attach and detach slaves
- Master-slave switch
- Establishing *SCO* links
- Handling of low power modes (Sniff, Hold, Park)

The diagram shows a Master node and Slave nodes. A Slave node sends a 'req' message to the Master, and the Master sends a 'response' message back. A 'Paging' message is also shown between the Master and Slave nodes.

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 24

Low power mode (Park)

- Power saving + keep more than 7 slaves in a piconet
- Give up active member address, yet maintain synchronization
- Communication via broadcast LMP messages

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 25

Connection establishment & Security

- Goals
 - Authenticated access
 - Only accept connections from trusted devices
 - Privacy of communication
 - prevent eavesdropping
- Constraints
 - ▶ Processing and memory limitations
 - \$10 headsets, joysticks
 - ▶ Cannot rely on PKI
 - ▶ Simple user experience

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 26

Authentication

- Authentication is based on link key (128 bit shared secret between two devices)
- How can link keys be distributed securely ?

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 27

Link Manager Protocol Summary

- Piconet management
- Link configuration
 - Low power modes
 - QoS
 - Packet type selection
- Security: authentication and encryption

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks

L2CAP

Logical Link Control and Adaptation Protocol

L2CAP provides

- Protocol multiplexing
- Segmentation and Re-assembly
- Quality of service negotiation

Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 29

Why baseband isn't sufficient

Baseband \leftrightarrow reliable*, flow controlled
in-sequence, asynchronous link

- Baseband packet size is very small (17min, 339 max)
- No protocol-id field in the baseband header


Renato.LoCigno@dit.unitn.it Nomadic Communications: Short Range Networks 30

Example usage of SDP

- Establish L2CAP connection to remote device
- Query for services
 - search for specific class of service, or
 - browse for services
- Retrieve attributes that detail how to connect to the service
- Establish a separate (non-SDP) connection to use the service



Serial Port Emulation using RFCOMM



Serial Port emulation on top of a packet oriented link

- Similar to HDLC
- For supporting legacy apps




ZigBee and 802.15.4 for Personal Area and Sensor Networks

The ZigBee Alliance Solution


- Targeted at home and building automation and controls, consumer electronics, PC peripherals, medical monitoring, and toys
- Industry standard through application profiles running over IEEE 802.15.4 radios
- Primary drivers are **simplicity, long battery life, networking capabilities, reliability, and cost**
- Alliance provides interoperability and certification testing




The Wireless Market



Applications






- ### MAC Options
- Two channel access mechanisms
- Non-beacon network
 - Standard CSMA-CA communications
 - Positive acknowledgement for successfully received packets
 - Beacon-enabled network
 - Superframe structure
 - For dedicated bandwidth and low latency
 - Set up by network coordinator to transmit beacons at predetermined intervals
 - 15ms to 252sec
($15.38ms * 2^n$ where $0 \leq n \leq 14$)
 - 16 equal-width time slots between beacons
 - Channel access in each time slot is contention free
- Renato.LoCigno@dit.univr.it Nomadic Communications: Short Range Networks 44

- ### Non-Beacon vs Beacon Modes
- Non-Beacon Mode
 - A simple, traditional multiple access system used in simple peer and near-peer networks
 - Think of it like a two-way radio network, where each client is autonomous and can initiate a conversation at will, but could interfere with others unintentionally
 - However, the recipient may not hear the call or the channel might already be in use
 - Beacon Mode
 - A powerful mechanism for controlling power consumption in extended networks like cluster tree or mesh
 - Allows all clients in a local piece of the network the ability to know when to communicate with each other
 - Here, the two-way radio network has a central dispatcher who manages the channel and arranges the calls
 - As you'll see, the primary value will be in system power consumption
- Renato.LoCigno@dit.univr.it Nomadic Communications: Short Range Networks 45

Example of Non-Beacon Network

- Commercial or home security
 - Client units (intrusion sensors, motion detectors, glass break detectors, standing water sensors, loud sound detectors, etc)
 - Sleep 99.999% of the time
 - Wake up on a regular yet random basis to announce their continued presence in the network ("12 o'clock and all's well")
 - When an event occurs, the sensor wakes up instantly and transmits the alert ("Somebody's on the front porch")
 - The ZigBee Coordinator, mains powered, has its receiver on all the time and so can wait to hear from each of these station.



Example of Beacon Network

- Now make the ZigBee Coordinator battery-operated also
 - All units in system are now battery-operated
 - Client registration to the network
 - Client unit when first powered up listens for the ZigBee Coordinator's network beacon (interval between 0.015 and 252 seconds)
 - Register with the coordinator and look for any messages directed to it
 - Return to sleep, awaking on a schedule specified by the ZigBee Coordinator
 - Once client communications are completed, ZigBee coordinator also returns to sleep



ZigBee and Bluetooth


Optimized for different applications

- | | |
|---|--|
| <ul style="list-style-type: none"> • ZigBee <ul style="list-style-type: none"> - Smaller packets over large network - Mostly Static networks with many, infrequently used devices - Home automation, toys, remote controls, etc. | <ul style="list-style-type: none"> • Bluetooth <ul style="list-style-type: none"> - Larger packets over small network - Ad-hoc networks - File transfer - Screen graphics, pictures, hands-free audio, Mobile phones, headsets, PDAs, etc. |
|---|--|



ZigBee and Bluetooth

Address Different Needs



- Bluetooth is a cable replacement for items like Phones, Laptop Computers, Headsets
- Bluetooth expects regular charging
 - Target is to use <10% of host power



ZigBee and Bluetooth

Address Different Needs

- ZigBee is better for devices where the battery is 'rarely' replaced
 - Targets are :
 - Tiny fraction of host power
 - New opportunities where wireless not yet used



An Application Example

Battery Life & Latency in a Light Switch

- **Wireless Light switch**
 - Easy for Builders to Install
- **A Bluetooth Implementation would:**
 - use the inquiry procedure to find the light each time the switch was operated.



Light switch using Bluetooth

- Inquiry procedure to locate light each time switch is operated
 - Bluetooth 1.1 = up to 10 seconds typical
 - Bluetooth 1.2 = several seconds even if optimized

- Unacceptable latency



Light switch using ZigBee

- With DSSS interface, only need to perform CSMA before transmitting
 - Only 200 μ s of latency
 - Highly efficient use of battery power

ZigBee offers longer battery life and lower latency than a Bluetooth equivalent



Wireless Keyboard

- Battery-operated keyboard
 - Part of a device group including a mouse or trackball, sketchpad, other human input devices
 - Each device has a unique ID
 - Device set includes a USB to wireless interface dongle
 - Dongle powered continuously from computer
 - Keyboard does not have ON/OFF switch
- Power modes
 - Keyboard normally in lowest power mode
 - Upon first keystroke, wakes up and stays in a "more aware" state until 5 seconds of inactivity have passed, then transitions back to lowest power mode



Keyboard Usage

- **Typing Rates**
 - 10, 25, 50, 75 and 100 words per minute
- **Typing Pattern**
 - Theoretical: Type continuously until battery is depleted
 - Measures total number of hours based upon available battery energy



Wireless Keyboard Using 802.15.4

- **802.15.4 Operation Parameters**
 - Star network
 - Non-beacon mode (CSMA-CA)
 - USB Dongle is a PAN Coordinator Full Functional Device (FFD)
 - Keyboard is a Reduced Function Device (RFD)
 - **Power Modes**
 - Quiescent Mode used for lowest power state
 - » First keystroke latency is approx 25ms
 - Idle mode used for "more aware" state
 - » Keystroke latency 8-12 ms latency



Wireless Keyboard Using 802.15.4

- **802.15.4 Chipset Parameters**
 - Motorola 802.15.4 Transceiver and HCS08 MCU
 - Battery operating voltage 2.0 - 3.6 V
 - All required regulation internal to ICs
 - Nearly all available energy usable with end of life voltage at 2.0 volts




Wireless Keyboard Using Bluetooth

- Bluetooth Operation Parameters
 - Piconet network
 - USB Dongle is piconet Master
 - Keyboard is a piconet Slave
 - Power Modes
 - Park mode used for lowest power state
 - » 1.28 second park interval
 - » First keystroke latency is 1.28s
 - Sniff mode used for "more aware" state
 - » 15ms sniff interval
 - » 15ms latency



BT vs. 15.4 Keyboard Comparison



Why BT and ZigBee are so different?

- Bluetooth and 802.15.4 transceiver physical characteristics are very similar
- Protocols are substantially different and designed for different purposes
- 802.15.4 designed for low to very low duty cycle static and dynamic environments with many active nodes
- Bluetooth designed for high QoS, variety of duty cycles, moderate data rates in fairly static simple networks with limited active nodes
- Bluetooth costs and system performance are in line with 3rd and 4th generation products hitting market while 1st generation 15.4 products will be appearing only late this year